

Printer

Supported protocols

TCP/IP

| Printer model | Note |
|------------------------------|--------|
| Canon | |
| MP960 | *2, *7 |
| MP950 | *2 |
| MP810 | *2 |
| MP800 | *2 |
| MP780 | *2 |
| MP760 | *1 |
| MP750 | *2 |
| MP600 | *2, *7 |
| MP510 | *2 |
| MP500 | *2 |
| MP460 | *2 |
| MP450 | *2 |
| MP370 | |
| MP180 | *2 |
| MP170 | *2 |
| MP160 | *2 |
| MP130 | |
| MP110 | |
| iP8500 | |
| iP6700D | |
| iP6600D | |
| iP6320D | |
| iP6310D | |
| iP6220D | |
| iP6210D | |
| iP5300 | *7 |
| iP5200 | |
| iP4300 | *7 |
| iP4200 | |
| iP4000 | |
| iP3300 | |
| iP3000 | |
| iP2200 | |
| iP1700 | |
| iP1600 | |
| iP1500 | |
| iP90 | |
| i950 | |
| i470D | |
| DELL | |
| All-in-One Photo Printer 922 | |
| DYMO | |
| LabelWriter duo | |
| LabelWriter TwinTurbo | |
| LabelWriter 400 turbo | |
| LabelWriter 400 | |

| | |
|-----------------------|------------|
| LabelWriter 330 turbo | |
| LabelWriter 320 | |
| LabelWriter 310 | |
| HP | |
| deskjet 5740 | |
| deskjet 5650 | |
| deskjet 5551 | |
| deskjet 948C | |
| Photosmart 2610 | *3, *4, *5 |
| PSC 2450 | *3, *4, *5 |
| PSC 2355 | *3, *4, *5 |
| PSC 1315 | *3, *4, *5 |
| OfficeJet 6210 | *1, *3 |
| Konica Minolta | |
| PagePro 1380MF | |
| PagePro 1390MF | |
| Lexmark | |
| Z810 | |
| X5250 | |

*1 This model does not support PC fax function.

*2 An image data in a memory card cannot be read through "MP Navigator ", the utility attached to a MFP.

*3 Scanning operation cannot be carried out in the scanning software of the printer attachment CD.

*4 Scan can be carried out in the scanning wizard (WIA) for OS preinstallation.

*5 Scan can be carried out by the TWAIN driver.

*6 Please use firmware version 1.1.0 or later.

*7 Please connect MFP to PC directly when you install attached software "MP Navigator Ver3.0.0".

Scanner

Supported OS

Windows 2000, Windows XP

| Scanner model | Note |
|-----------------------------|------|
| Avision Simplex Color AV121 | |
| Avision AV210C2 | |
| Avision AV220C2 | |
| Avision AV3850SU | |
| CANON CanoScan LiDE500F | |
| CANON CanoScan LiDE80 | |
| CANON CanoScan LiDE50 | |
| CANON CanoScan LiDE40 | |
| CANON CanoScan 5200F | |
| CANON CanoScan 5000F | |
| CANON CanoScan D1250U2 | |
| EPSON GT-9400UF | |
| EPSON GT-8200U | |
| EPSON GT-7700U | |
| EPSON GT-7400U | |
| EPSON GT-F600 | |
| EPSON GT-F550 | |
| EPSON GT-F500 | |
| EPSON GT-X800 | |
| Fujitsu fi-5530C | |
| Kodak i40 Scanner | |
| Kodak i30 Scanner | |
| Mikrotek ScanMaker 5950 | |
| Panasonic KV-S3065CW | |
| Panasonic KV-S3065CL | |
| PFU fi-5110EOX2 | |
| Xerox DocuMate 262 | *1 |

*1 Please make sure to use at least OneTouch 4.0.6.1013 if you want to use the scan button.

Storage

Supported OS

Windows 2000, Windows XP

| | Storage model | Note |
|----------------------|---|------|
| Digital camera | Canon IXY DIGITAL 30 | *1 |
| | Canon IXY DIGITAL L | |
| | Fujifilm FinePix F440 | |
| | Fujifilm FinePix S5 Pro | *1-A |
| | Panasonic LUMIX DMC-FX7 | |
| | Panasonic LUMIX DMC-F1 | |
| USB memory | BUFFALO ClipDrive RUF-C32M | |
| | IO DATA EDP2-512M | *1 |
| | IO DATA EDP-128M | *1 |
| | Hagiwara SYS-COM HUD-512PJ | |
| | | |
| Card reader | BUFFALO MCR-C8/U2 | |
| | BUFFALO MCR-8U/U2 | |
| | Panasonic BN-SDCGP3 | |
| | SONY MSAC-US30 | |
| | TDK U2RW01CMS | |
| Audio player | Apple iPod 20GB SpecialEdition [M9787J/A] | |
| HDD | BUFFALO HD-250U2 | |
| | BUFFALO HD-160U2 | |
| | BUFFALO HD-HB250U2 | |
| | BUFFALO HD-PH80U2/BST | |
| | BUFFALO HD-P80U2/UC | |
| | BUFFALO HD-P40U2/UC | |
| | BUFFALO DUB2-B120G | |
| | DViCO M3000U | |
| | EPSON P-2000 | |
| | IO DATA HDH-U250S | |
| | IO DATA HDH-U250 | |
| | IO DATA HDH-U160S | |
| | IO DATA HDH-U160 | |
| | IO DATA HDA-iU120 | |
| | IO DATA HDW-UE320 | |
| Logitech LHD-PBH40U2 | | |
| DVD-R/RW | BUFFALO DVSM-DH516U2 | *2 |
| | BUFFALO DVM-RDH16U2 | *2 |
| | IO-DATA DVR-UM16A | *2 |
| | IO-DATA DVR-iUN8WR | *2 |
| | IO-DATA DVR-iUN4 | *2 |
| | Panasonic LF-P767C | *3 |
| USB HUB | Corega CG-UHUB4P | *4 |
| | ELECOM U2H-K4BSV | *4 |
| | ELECOM U2H-S4SSV | *4 |
| | GreenHouse GH-UHC204BW | *4 |
| | LOAS UH-1104W | *4 |
| | LOAS UH-224SL | *4 |
| | LOAS UH-204GM | *4 |
| | RIX USB-003-BS | *4 |
| | RIX USB-002-BL | *4 |
| SIGMA SHBH-4SV | *4 | |

*1 An attached utility cannot be used.

*1-A Please use latest SX Virtual Link. The connection has been confirmed with FUJIFILM Hyper-Utility Software HS-V3.

*2 A write-error or a bit error may occur depending on the network condition.

*3 A diagnostic tool for bus power that is attached to DVD-R/RW is not available.

*4 If an AC adapter is attached to a USB hub, please use it.